



# INDIAN INSTITUTE OF TECHNOLOGY HYDERABAD

BIOMEDICAL IMAGING

# CT IMAGING

Abhishek Amit Raje

February 2024

## 1 *Sinogram of a Shepp Logan Phantom*

- A sinogram is a graphical representation of the intensity values obtained from a set of projections of an object. It is the projected sum of the 1D Fourier transforms taken about the image.
- The sinogram is represented as a 2D plot where the x-axis corresponds to the projection angle  $\theta$  and the y-axis corresponds to the radial distance  $\rho$ . Each point in the sinogram represents the integral of the attenuation along a specific ray at a specific angle.

```
1 import numpy as np
2 import matplotlib.pyplot as plt
3 from skimage.data import shepp_logan_phantom
4 from skimage.transform import radon
5
6 def generate_sinogram_with_theta(phantom, theta, cmap='
    viridis'):
7     sinogram = radon(phantom, theta=theta, circle=True)
8
9     plt.subplot(121)
10    plt.imshow(phantom, cmap='gray')
11    plt.title('Shepp-Logan Phantom')
12
13    plt.subplot(122)
14    plt.imshow(sinogram, cmap=cmap, aspect='auto', extent=[
    min(theta), max(theta), 0, sinogram.shape[0]])
15    plt.colorbar(label='Intensity')
16    plt.title('Sinogram' )
17
18    plt.show()
19
20 # Generate Shepp-Logan phantom
21 phantom = shepp_logan_phantom()
22
23 # Specify the sampling angle theta (in degrees) with a
    sampling rate of 0.05 degrees
24 theta_values = np.arange(0, 180,0.05)
25
26 # Generate sinogram with specified theta values
27 generate_sinogram_with_theta(phantom, theta_values)
```

Listing 1: Python code for generating sinogram




Figure 1: Sinogram at a sampling rate  $\theta = 0.5$  degree

## 2 *Filtered Back Projection*

- Filtered back projection is a reconstruction technique commonly used in computed tomography (CT) and other medical imaging modalities.
- It is employed to convert the acquired projection data (sinogram) back into a two-dimensional image of the internal structure of an object.
- A filter is applied to the sinogram data to enhance specific frequency components and reduce artifacts in the reconstructed image.

```

1 import numpy as np
2 import matplotlib.pyplot as plt
3 from scipy.ndimage import convolve1d
4 from skimage.data import shepp_logan_phantom
5 from skimage.transform import radon
6
7 def generate_sinogram_with_theta(phantom, theta, cmap='
  viridis'):
8     sinogram = radon(phantom, theta=theta, circle=True)
9
10    # Apply Mexican Hat filter
11    mexican_hat_kernel = np.array([-1, 2, -1])
12    filtered_sinogram = convolve1d(sinogram,
13    mexican_hat_kernel, axis=0, mode='constant', cval=0)
14
15    fig, axes = plt.subplots(1, 3, figsize=(15, 5)) # 1 row
16    , 3 columns

```

```

15
16 axes[0].imshow(phantom, cmap='gray')
17 axes[0].set_title('Shepp-Logan Phantom')
18
19 im1 = axes[1].imshow(sinogram, cmap=cmap, aspect='auto',
20 extent=[min(theta), max(theta), 0, sinogram.shape[0]])
21 axes[1].set_title('Original Sinogram')
22 plt.colorbar(im1, ax=axes[1], label='Intensity') # Add
23 colorbar to the first subplot
24
25 im2 = axes[2].imshow(filtered_sinogram, cmap=cmap,
26 aspect='auto', extent=[min(theta), max(theta), 0,
27 filtered_sinogram.shape[0]])
28 axes[2].set_title('Sinogram with Mexican Hat Filter')
29 plt.colorbar(im2, ax=axes[2], label='Intensity') # Add
30 colorbar to the second subplot
31
32 plt.subplots_adjust(wspace=0.5) # Adjust the width
33 space between subplots
34
35 plt.show()
36
37 # Generate Shepp-Logan phantom
38 phantom = shepp_logan_phantom()
39
40 # Specify the sampling angle theta (in degrees) with a
41 sampling rate of 0.05 degrees
42 theta_values = np.arange(0, 180, 0.05)
43
44 # Generate sinogram with specified theta values and apply
45 Mexican Hat filter
46 generate_sinogram_with_theta(phantom, theta_values)

```

Listing 2: Python code for generating sinogram with Mexican Hat filter




Figure 2: Singogram with Mexican Hat Filter

### Comparing Properties

- As Observed the Mexican Hat filter enhances certain frequency components in the sinogram while suppressing others.
- The sinogram with the Mexican Hat filter is has sharper features
- The filtering process reduces noise in the sinogram, leading to a cleaner representation of the object's attenuation characteristics

]

### 3 *Reconstruction of Image*

```
1 import numpy as np
2 import matplotlib.pyplot as plt
3 from skimage.data import shepp_logan_phantom
4 from skimage.transform import radon, iradon
5
6 def generate_sinogram_with_theta(phantom, theta, cmap='
viridis'):
7     sinogram = radon(phantom, theta=theta, circle=True)
8     plt.subplot(121)
9     plt.imshow(phantom, cmap='gray')
10    plt.title('Shepp-Logan Phantom')
11
12    plt.subplot(122)
13    plt.imshow(sinogram, cmap=cmap, aspect='auto', extent=[
min(theta), max(theta), 0, sinogram.shape[0]])
14    plt.colorbar(label='Intensity')
15    plt.title('Sinogram' )
16
17    plt.show()
18
19    return sinogram
20
21 def reconstruct_image_from_sinogram(sinogram, theta):
22     reconstructed_image = iradon(sinogram, theta=theta,
circle=True)
23
24     plt.imshow(reconstructed_image, cmap='gray')
25     plt.title('Reconstructed Image')
26     plt.show()
27
28 # Generate Shepp-Logan phantom
29 phantom = shepp_logan_phantom()
30
31 # Specify the sampling angle theta (in degrees) with a
sampling rate of 0.05 degrees
32 theta_values = np.arange(0, 180, 5)
33
34 # Generate sinogram with specified theta values
35 sinogram = generate_sinogram_with_theta(phantom,
theta_values)
36
37 # Reconstruct the image from the sinogram
38 reconstruct_image_from_sinogram(sinogram, theta_values)
```

Listing 3: Reconstructing Sinogram using Inverse Radon Transform




Figure 3: Reconstruction at sampling angle  $\theta = 5$  degree




Figure 4: Reconstruction at sampling angle  $\theta = 0.5$  degree i.e 360 projections

## 4 *Sinogram using 360-degree projection*

### Effect of Sampling Rate on Image Reconstruction

- Insufficient sampling can lead to aliasing artifacts in the reconstructed image
- When the angle of sampling is too sparse, streaking artifacts may appear in the reconstructed image
- Increasing the number of projections (higher sampling rate) generally improves the resolution and sharpness of the reconstructed image.



## 5 *Reconstruction Using Central Slice Theorem*

```
1 import numpy as np
2 import matplotlib.pyplot as plt
3 from skimage.data import shepp_logan_phantom
4 from skimage.transform import radon, iradon
5
6 # Generate Shepp-Logan phantom
7 phantom = shepp_logan_phantom()
8
9 # Perform Radon transform to obtain sinogram
10 sinogram = radon(phantom)
11
12 # Apply Central Slice Theorem by taking the inverse Radon
13   transform
14 reconstructed_image = iradon(sinogram)
15
16 # Display the results
17 plt.figure(figsize=(10, 4))
18
19 plt.subplot(131)
20 plt.imshow(phantom, cmap='gray')
21 plt.title('Shepp-Logan Phantom')
22
23 plt.subplot(132)
24 plt.imshow(sinogram, cmap='viridis', aspect='auto', extent
25           =[0, 180, 0, sinogram.shape[0]])
26 plt.title('Sinogram')
27
28 plt.subplot(133)
29 plt.imshow(reconstructed_image, cmap='gray')
30 plt.title('Reconstructed Image')
31
32 plt.show()
```

Listing 4: Reconstructing Sinogram using Central Slice Theorem

- the Central Slice Theorem states that the Fourier transform of a 1D projection of an object is equivalent to a central line in the 2D Fourier transform of the object itself.




Figure 5: Reconstruction using central Slice Theorem

## 6 *Reconstruction After Filtering*

```

1 import numpy as np
2 import matplotlib.pyplot as plt
3 from skimage.data import shepp_logan_phantom
4 from skimage.transform import radon, iradon
5
6 def apply_filter(sinogram, filter_type):
7     projections = radon(sinogram, circle=True)
8     # Apply frequency domain filter
9     if filter_type == 'ram-lak':
10         filter_func = np.abs(np.fft.fftshift(np.fft.fft(np.
11             fft.ifftshift(np.arange(-len(projections)//2, len(
12                 projections)//2))))))
13     elif filter_type == 'shepp-logan':
14         filter_func = np.abs(np.fft.fftshift(np.fft.fft(np.
15             fft.ifftshift(np.sqrt(np.abs(np.arange(-len(projections)
16                 //2, len(projections)//2)))))))))
17     elif filter_type == 'cosine':
18         filter_func = np.abs(np.fft.fftshift(np.fft.fft(np.
19             fft.ifftshift(np.cos(np.arange(-len(projections)//2, len(
20                 projections)//2) * np.pi / len(projections))))))
21     elif filter_type == 'hamming':
22         filter_func = np.abs(np.fft.fftshift(np.fft.fft(np.
23             fft.ifftshift(0.54 + 0.46 * np.cos(2 * np.pi * np.arange
24                 (-len(projections)//2, len(projections)//2) / len(
25                     projections))))))
26
27     filtered_projections = projections * filter_func
28     return filtered_projections, angles
29
30 def reconstruct_image(sinogram, angles):
31     reconstructed_image = iradon(sinogram, theta=angles,

```

```

    circle=True)
23     return reconstructed_image
24
25 # Generate Shepp-Logan phantom
26 phantom = shepp_logan_phantom()
27
28 # Specify the sampling angle theta (in degrees)
29 theta_values = np.arange(0, 180, 1)
30
31 # Generate sinogram with specified theta values
32 sinogram = radon(phantom, theta=theta_values, circle=True)
33
34 # Define filter types
35 filter_types = ['ram-lak', 'shepp-logan', 'cosine', 'hamming
    ']
36
37 # Perform filtered backprojection with different filters
38 for filter_type in filter_types:
39     filtered_sinoam, angles = apply_filter(sinogram,
40     filter_type)
41     reconstructed_image = reconstruct_image(
42     filtered_sinogram, angles)
43
44 # Display results
45 plt.figure(figsize=(12, 4))
46 plt.subplot(131)
47 plt.imshow(phantom, cmap='gray')
48 plt.title('Original Image')
49
50 plt.subplot(132)
51 plt.imshow(reconstructed_image, cmap='gray')
52 plt.title(f'Reconstructed Image ({filter_type.capitalize
53 ()} Filter)')
54
55 plt.subplot(133)
56 plt.plot(angles, filtered_sinogram.mean(axis=0), label='
57 Filtered Sinogram')
58 plt.legend()
59 plt.title('Filtered Sinogram')
60
61 plt.show()

```

Listing 5: Reconstructing Sinogram After Filtering




Figure 6: Reconstructing after Filtering

## **7    *Limitations of projection radiography***

- Projection radiography provides a two-dimensional image of the internal structures, which can lead to overlapping of structures and difficulties in accurately assessing the depth or three-dimensional relationships.
- Traditional projection radiography provides static images, and it is not suitable for real-time imaging
- Various artifacts, such as image distortion or blurring, may occur due to patient movement, equipment malfunctions, or other external factors

# X-RAY IMAGING

Abhishek Amit Raje

February 2024

## 1 *Factor Affecting SNR*

Signal-to-Noise Ratio (SNR) in X-ray imaging is influenced by various factors

- **Scatter Radiation:** Scatter radiation contributes to noise in the image
- **Detector Efficiency:** The efficiency of the detector in converting X-ray photons
- **Patient Thickness and Density:** The composition and thickness of the patient's body influence the attenuation of X-rays

If the SNR doubles then dose becomes four times

## 2 *Beam Hardening*

- Beam hardening is a phenomenon in X-ray imaging that occurs when a polychromatic X-ray beam, which consists of a range of energy levels, passes through an object or a patient. As the X-ray beam traverses through different materials of varying thickness and composition
- In this process lower-energy X-ray photons are preferentially absorbed, leading to an increase in the average energy of the remaining X-ray beam.

## 3 *Aliasing, bandwidth limiting, Nyquist condition*

- **Aliasing:** Aliasing occurs when a signal is undersampled, causing high-frequency components to inaccurately fold into lower frequencies
- **Bandwidth limiting** Bandwidth limiting restricts the range of frequencies in a signal, crucial for controlling information transmission and avoiding interference.
- **Nyquist condition** The Nyquist condition sampling theorem, dictates that the sampling rate must be at least twice the maximum frequency in a signal to prevent aliasing. This condition is expressed as  $f_s > 2_{max}$

## 4 *Percentage of X-rays are transmitted through the chest*

We know percentage of X-rays transmitted through the chest, the exponential attenuation formula:

$$I = I_o e^{-ux} \quad (1)$$

where:

- I is the intensity of the transmitted X-rays

- $I_o$  is the initial intensity of the incident X-rays
- $u$  is the linear attenuation coefficient
- $x$  is the thickness of the material.

The linear attenuation coefficient  $u$  can be calculated using the half-value layer (HVL) ( $H$ ) and the formula

$$u = \frac{\ln 2}{H} \quad (2)$$

Calculate  $u$  for muscle and bone

$$\mu_{\text{muscle}} = \frac{0.693}{3.5 \text{ cm}} \approx 0.198 \text{ cm}^{-1}$$

$$\mu_{\text{bone}} = \frac{0.693}{1.8 \text{ cm}} \approx 0.385 \text{ cm}^{-1}$$

$$I_{\text{muscle}} = I_o \cdot e^{-\mu_{\text{muscle}} \cdot x_{\text{muscle}}} = I_o \cdot e^{-0.198 \cdot 16}$$

$$I_{\text{bone}} = I_o \cdot e^{-\mu_{\text{bone}} \cdot x_{\text{bone}}} = I_o \cdot e^{-0.385 \cdot 4}$$

$$I_{\text{total}} = I_{\text{muscle}} \cdot I_{\text{bone}}$$

Percentage of X-Ray Transmitted

$$e^{-0.198} * e^{-0.385} = e^{-0.583} = 0.558$$

## 5 *Difference between X-Ray Images*

- Higher Effective Energy (140 keV): X-rays with higher energy penetrate tissues more effectively. This results in lower contrast in the image because the X-rays making it challenging to distinguish
- Lower Effective Energy (50 keV): Lower energy X-rays are more readily absorbed by soft tissues, leading to increased contrast.
- Higher Effective Energy (140 keV): The X-rays with higher energy can penetrate the body more deeply, reaching the detector with less attenuation.
- Lower Effective Energy (50 keV): Lower energy X-rays are more likely to be absorbed by tissues, leading to greater attenuation.




## 6 *Opinion on getting Xray imaging for heart related diseases.*

| Pros  | Cons   |
|---|--|
| <ul style="list-style-type: none"><li>• Diagnostic Tool: X-ray imaging can provide valuable information about the structure of the heart.</li><li>• Quick and Non-Invasive: X-rays are relatively quick and non-invasive compared to some other imaging modalities.</li><li>• Widely Available: X-ray facilities are widely available, making it a convenient option for initial screening.</li></ul> | <ul style="list-style-type: none"><li>• Radiation Exposure: X-rays involve exposure to ionizing radiation, which carries potential risks.</li><li>• Limited Soft Tissue Detail: X-rays are better at visualizing bones and dense structures but have limitations in capturing detailed images of soft tissues.</li><li>• May Require Contrast Agents: In some cases, contrast agents may be used, and individuals may have allergies or adverse reactions to these agents.</li></ul> |

## 7 *Fourier Transforms and Spectra*

a.  $\cos^2(k_0 z)$

$$\mathcal{F}\{\cos^2(k_0 z)\} = \frac{1}{2} [\delta(\omega - k_0) + \delta(\omega + k_0)]$$



b.  $\sin^3(k_0 z)$

$$\mathcal{F}\{\sin^3(k_0 z)\} = \frac{3}{4i} [\delta(\omega - 3k_0) - \delta(\omega - k_0)]$$

